

CLEAR AMOUNT USED

Clears or resets the "AMOUNT USED" and "DAILY USAGE" display to zero.

Digital Display

Action Required - Press "ENTER" after completing each step.

Step 1

CLEAR AMOUNT USED
THEN PRESS ENTER

Press **ENTER** to continue.

Step 2

CLEAR ALL SCALES
1 = Y 0 = N X

Enter **1** to clear all scales....or (if "1" entered, skip Step 3)

Enter **0** to clear individual scales (go to Step 3)

Step 3

ENTER SCALE #
1 THRU 4 X

If you chose INDIVIDUAL scales....

Enter the NUMBER of the scale you want to enter a Tare Weight.
Choose scale 1, 2, 3 or 4

Step 4

ARE YOU SURE?
1 = Y 0 = N X

Enter **1** for YES...

Enter **0** for NO

SET SCALE ZERO / TARE

Allows the user re-zero the display if it has drifted or changed, OR enter the TARE WEIGHT of the tank.

PORTABLE TANK APPLICATIONS

Digital Display

Action Required - Press "ENTER" after completing each step.

Step 1

SET SCALE ZERO
THEN PRESS ENTER

Press **ENTER** to continue.

Step 2

ARE YOU SURE?
1 = Y 0 = N X

Enter **1** for YES....or

Enter **0** for NO

Step 3

ENTER SCALE #
1 THRU 4 X

Enter the NUMBER of the scale you want to enter a Tare Weight.
Choose scale 1, 2, 3 or 4

FIXED TANK APPLICATIONS

Digital Display

Action Required - Press "ENTER" after completing each step.

Step 1

ZERO / TARE
THEN PRESS ENTER

Press **ENTER** to continue.

Step 2

ARE YOU SURE?
1 = Y 0 = N X

Enter **1** for YES....or

Enter **0** for NO

Step 3

ENTER SCALE #
1 THRU 4 X

Enter the NUMBER of the scale you want to enter a Tare Weight.
Choose scale 1, 2, 3 or 4

